

Tank top return-line filter

Pi 5000

Nominal size 160 up to 1000 according to DIN 24550


1. Features

High performance filters for modern hydraulic systems

- Provided for tank top installation
- Modular system
- Compact design
- Minimal pressure drop through optimal flow design
- Visual/electrical/electronic maintenance indicator
- Threaded connections
- Quality filters, easy to service
- Equipped with highly efficient glass fibre Sm-x filter elements
- Beta rated elements according to ISO 16889 multipass test
- Elements with high differential pressure stability and dirt holding capacity
- NPT- and SAE-connections on request
- Worldwide distribution



2. Flow rate/pressure drop curve complete filter



y = differential pressure Δp [bar]

x = flow rate V [l/min]

- *1 6
- 1. Sm-x 3
- 2. Sm-x 6
- 3. Sm-x 10
- 4. Sm-x 16
- 5. Sm-x 25
- 6. Mic 10

3. Separation grade characteristics

y = beta-value

x = particle size [µm]

determined by multipass tests (ISO 16889) calibration according to ISO 1171 (NIST)

4. Filter performance data

tested according to ISO 16889 (multipass test)

Sm-x elements with max. Δ p 10 bar

 $\beta_{5(C)}$ Sm-x ≥200 Sm-x $\beta_{7(C)}$ ≥200 ≥200 Sm-x 10 $\beta_{10(C)}$ Sm-x $\beta_{15(C)}$ ≥200 Sm-x 25 ≥200 $\beta_{20(C)}$


values guaranteed up to 10 bar differential pressure

5. Quality assurance

MAHLE filters and filter elements are produced according to the following international standards:

Norm	Designation
DIN ISO 2941	Hydraulic fluid power filter elements; verification of collapse/burst resistance
DIN ISO 2942	Hydraulic fluid power filter elements; verification of fabrication integrity
DIN ISO 2943	Hydraulic fluid power filter elements; verification material compatibility with fluids
DIN ISO 2923	Fluidtechnik-Hydraulik Filterelemente; method for end load test
DIN ISO 2924	Hydraulic fluid power filter elements; verification of flow fatigue characteristics
ISO 3968	Hydraulic fluid power filters; evaluation of pressure drop versus flow characteristics
ISO 10771.1	Fatigue pressure testing of metal containing envelopes in hydraulic fluid applications
ISO 16889	Hydraulic fluid power filters; multipass method for evaluation filtration performance of a filter element

6. Symbols



7. Order numbers

Example for ordering filters:

1. Housing design	2. Filter element
Bypass valve 3.5 bar, Connection execution 2 = DN 38	Sm-x 25 NBR
Type: Pi 50016-056/NG 160	Type: Pi 2516 RN

				2	3		5	(5)	
				with	with		with	with	
		1		visual	electrical	4	pressure	pressure	with
		with	1	mainte-	main-	with	switch	switch	filling
Nominal		bypass	with	nance	tenance	pressure	normally	normally	connec-
size	Housing	valve	indicator	indicator	indicator	gauge	open	closed	tion
NG [l/min]	code	3.5 bar	cavity	2.2 bar	2.2 bar	(DM)	(DSS)	(DSO)	(BA)
	- 047								
	- 056								
	- 057								
	- 058								
160	- 059								
250	- 050								
400	- 052								
630	- 092								
1000	- 093								
	- 094								
	- 095								
	- 096								
	- 097								

^{*} a wider range of executions is available on request

.2 Connection ex Nominal size NG [I/min]	Type	Standard connection according DIN 24550 part 1	/1	/2	/3	/4	/5	/6
160	Pi 50016	G1¼	G1½	DN 38				
250	Pi 50025	G1½		DN 38	G1¼			
400	Pi 50040	DN 51	G1½			G2	DN 64	
630	Pi 50063	DN 64	G1½			G2		DN 51
1000	Pi 50100	DN 76						

DN 38 = SAE $1\frac{1}{2}$ " DN 51 = SAE 2" DN 64 = SAE $2\frac{1}{2}$ " DN 76 = SAE 3" 3000 psi

Filter elements	S*				
Nominal size NG [l/min]	Order number	Type	Filter material	max. ∆ p [bar]	Filter surface [cm²]
NG [l/lilli]				[Dai]	3750
	77925035	Pi 13016 RN Mic 10 NBR Pi 21016 RN Sm-x 3 NBR	Mic 10		3750
	77924137		Sm-x 3		
160	77964067	Pi 22016 RN Sm-x6 NBR	Sm-x 6 Sm-x 10	10	3750
	77924145	Pi 23016 RN Sm-x10 NBR		3750	
	77963648	Pi 24016 RN Sm-x16 NBR	Sm-x 16		3750
	77960230	Pi 25016 RN Sm-x25 NBR	Sm-x 25		3750
	77925043	Pi 13025 RN Mic 10 NBR	Mic 10		6050
	77924152	Pi 21025 RN Sm-x 3 NBR	Sm-x 3		6050
250	77964075	Pi 22025 RN Sm-x6 NBR	Sm-x 6	10	6050
200	77924160	Pi 23025 RN Sm-x10 NBR	Sm-x 10	10	6050
	77963655	Pi 24025 RN Sm-x16 NBR	Sm-x 16		6050
	77960248	Pi 25025 RN Sm-x25 NBR	Sm-x 25		6050
	77925050	Pi 13040 RN Mic 10 NBR	Mic 10		9450
	77924178	Pi 21040 RN Sm-x 3 NBR	Sm-x 3		9450
400	77964083	Pi 22040 RN Sm-x6 NBR	Sm-x 6	40	9450
400	77924186	Pi 23040 RN Sm-x10 NBR	Sm-x 10	10	9450
	77963663	Pi 24040 RN Sm-x16 NBR	Sm-x 16		9450
	77960255	Pi 25040 RN Sm-x25 NBR	Sm-x 25		9450
	77925068	Pi 13063 RN Mic 10 NBR	Mic 10		15500
	77924194	Pi 21063 RN Sm-x 3 NBR	Sm-x 3		15500
	77964091	Pi 22063 RN Sm-x6 NBR	Sm-x 6		15500
630	77924202	Pi 23063 RN Sm-x10 NBR	Sm-x 10	10	15500
	77963671	Pi 24063 RN Sm-x16 NBR	Sm-x 16		15500
	77960263	Pi 25063 RN Sm-x25 NBR	Sm-x 25		15500
	77925076	Pi 13100 RN Mic 10 NBR	Mic 10		18700
	77924210	Pi 21100 RN Sm-x 3 NBR	Sm-x 3		18700
	77964109	Pi 22100 RN Sm-x6 NBR	Sm-x 6		18700
1000	77924228	Pi 23100 RN Sm-x10 NBR	Sm-x 10	10	18700
	77963689	Pi 24100 RN Sm-x16 NBR	Sm-x 16		18700
	77960271	Pi 25100 RN Sm-x25 NBR	Sm-x 25		18700

^{*}a wider range of element types is available on request

8. Technical specifications

Design: tank top mounting filter Nominal pressure : 10 bar (140 psi) Test pressure: 13 bar (180 psi) - 10 °C to + 80 °C Temperature range:

(other temperature ranges on request)

Bypass setting: Δ p 3.5 bar \pm 10 % Filter head material: GD AI Filter housing material: St.

GD AI/G AI Filter cover material: Δ p 2.2 bar \pm 10 %

Maintenance indicator setting:

Electrical data of maintenance indicator:

Maximum voltage: 250 V AC/200 V DC Maximum current: 1 A 70 W Contact load:

IP 65 in inserted and Type of protection:

secured status

Contact: normally open/closed Cable sleave: M20x1.5


The switching function can be changed by turning the electric upper part by 180° (normally closed contact or normally open contact). The state on delivery is a normally closed contact. By inductivity in the direct current circuit the use of suitable protection circuit should be considered. Further maintenance indicator details and designs are available in the maintenance indicator data sheet.


We draw attention to the fact that all values indicated are average values and do not always occur in specific cases of application. Our products are continually being further developed. Values, dimensions and weights can change as a result of this. Our specialized department will be pleased to offer you advice.


We recommend you to contact us concerning applications of our filters in areas governed by the EU Directive 94/9 EC (ATEX 95). The standard version can be used for liquids based on mineral oil (corresponding to the fluids in Group 2 of Directive 97/23 EC Article 9). If you consider to use other fluids please contact us for additional support.

Subject to technical alteration without prior notice.

- = Standard maintenance indicator visual PiS 3084
- 1 + 2 = Standard maintenance indicator electrical PiS 3085
- = Further executions see data sheet mainte-3 nance indicator
- = Pressure switch
- 4 + 5 = Can be mounted at I or II alternatively
- = Pressure gauge
- = Coupling for filling







9. Dimensions

All Dimensions except "L" in mm.

																	Weight
Type	Α	В	С	D	G	Н	ı	K	L	М	N	R	S	Т	U	V	[kg]
Pi 50016	185	40		207	135	130	94	52	G1½	11	47	162	93.5	70	35.7	M12	2.8
Pi 50025	185	40		297	135	130	94	52	G1½	11	47	162	93.5	70	35.7	M12	4.2
Pi 50040	220	55	see 7.2	309	175,5	163	118	70	G2	11	60	212	108	77.8	42.9	M12	6.4
Pi 50063	220	55	1.2	459	175,5	163	118	70	G2	11	60	212	108	89	50.8	M12	7.2
Pi 50100	250	70		430	200	190	149	-	G3	11	75	240	135	106.4	62	M16	10.6

10. Installation, operating and maintenance instructions

10.1 Filter installation

When installing the filter make sure that:

- a) that sufficient space is available to remove filter element and filter housing,
- b) the mounting hole in the tank top is not excessively large, to ensure proper sealing,
- c) the filter is free of tension after installation

Preferably the filter should be installed with the filter housing pointing downwards. In this position the maintenance indicator is accessible and visible.

10.2 Connecting the electricalmaintenance indicator

The electrical maintenance indicator is connected via a 2-pole appliance plug according to DIN EN 17 5301-803 with poles marked 1 and 2. The electrical section can be inverted to change from normally open position to normally closed position or vice versa.

10.3 When must the filter element be replaced?

- Filters equipped with visual and/or electrical maintenance indicator:
 - During cold starts, the indicator may give a warning signal. Press the button of the visual indicator once again only after operating temperature has been reached. If the red button immediately pops up again and/or the electrical signal has not switched off after reaching operating temperature, the filter element must be replaced after the end of the shift.
- 2. Filters without maintenance indicator:
 - The filter element should be replaced after trial run or flushing of the system. Afterward folow instructions of the manufacturer.
- Please always ensure that you have original MAHLE spare elements in stock: Disposable elements (Sm-x and Mic) cannot be cleaned.

10.4 Element replacement

- Stop system and relieve filter from pressure.
- 2. Unscrew cover, turning counter-clockwise.
- 3. Remove filter housing and filter element by pulling upwards.
- 4. Remove filter element with a side-to-side motion.
- 5. Clean the housing using a suitable cleaning solvent.
- Check O-ring on filter cover and filter housing for damage. Replace, if necessary.
- Make sure that the order number on the spare element corresponds to the order number of the filter name-plate.
- 8 . Remove filter element from the plastic bag and reassemble filter in reverse order (items 1 to 6).

Subject to technical alteration without prior notice.

11. Spare parts list

	Order number for spare part	s list							
Position	Туре	Order number							
	Seal kit for housing								
	NG 160/250								
	NBR	78227902							
	FPM	78227910							
	EPDM	78227928							
	NG 400/630								
1	NBR	78227936							
to ④	FPM	78227944							
O	EPDM	78227951							
	NG 1000								
	NBR	78227969							
	FPM	78227977							
	EPDM	78227985							
	Maintenance indicator								
	Visual PiS 3084/2.2	77669914							
	Electrical PiS 3085/2.2	77669864							
(5)	Electrical upper section only	77536550							
0	Pressure gauge	78381998							
	Pressure switch								
	Normally open	77845845							
	Normally closed	77870595							
	Seal kit for maintenance indicate	or							
6	NBR	78383382							
w .	FPM	78383390							
	EPDM	78383408							
7	Quick-release coupling	77965130							



MAHLE Filtersysteme GmbH Industriefiltration
Schleifbachweg 45
D-74613 Öhringen
Phone +49 (0) 7941/67-0
Fax +49 (0) 7941/67-23429
industriefiltration@mahle.com
www.mahle-industrialfiltration.com
70363178.03/2008